
APR2 Connection Diagram



- 1. Connect track power as shown to connectors. Right two contacts on each connector are shorted together.
- 2. Connect each service track to appropriate pin number on connector.

